

# Panel mounting fault annunciator

⇒



→ BSM - Panel-mounting fault annunciator (2nd generation)



MSM-BSM2G-BA-UK-002

28.06.2021

# Table of content

1 Validity	4
2 General notes	6
<ul> <li>2.1 Supplementary instructions</li> <li>2.2 Usage</li> <li>2.3 Target group</li> <li>2.4 Explanation of symbols</li> </ul>	6 6 6 6
<ul> <li>2.5 Safety instructions</li></ul>	8 8 8 8
3 Functional description	
3.1 Basic structure of the BSM         3.2 Internal Relay cards (optional)         3.3 Redundant power supply (optional)         3.4 Cascading of several fault indicators         3.5 Interfaces         3.6 Labeling         3.7 Control lights, buttons and connectors         3.8 Diagnostic functions.         3.8.1 Control light "Operating mode" and Alive Relay.         3.8.2 Error codes         3.9 Terminal assignments.         3.10.1 BSM 08.         3.10.2 BSM 16         3.10.3 BSM 16 in wide housing.         3.10.4 BSM 24.         3.10.5 BSM 32.         3.10.6 BSM 40.         3.10.7 BSM 48.         3.11 Input and signal light assignment	. 10 . 12 . 12 . 13 . 13 . 14 . 16 . 16 . 17 . 18 . 20 . 21 . 22 . 23 . 24 . 25 . 27
4 Mounting and installation	30 31
<ul> <li>5.1 Cascading functionality (DIP-switch combination S1)</li> <li>5.2 Alarm group related DIP-switch combinations (S10 – S20)</li> <li>5.3 Configuration of the relay groups</li> <li>5.4 Color configuration of the alarm lights through key combinations</li> <li>5.5 Default settings</li> </ul>	31 31 32 32 36
6 Parameterization	37
<ul> <li>6.1 Main menu "Language"</li> <li>6.2 Main menu "Information"</li> <li>6.3 Main menu "Parameter"</li> <li>6.3.1 Serial interface</li> <li>6.3.2 Menu "Device administration"</li> <li>6.3.2.1 Submenu "New/adapt"</li> <li>6.3.2.2 Submenu "New/adapt"</li> <li>6.3.3 System</li> <li>6.3.4 Menu "Fault annunciator" (Master device / Slave device 1 3)</li> <li>6.3.4.1 Submenu "Reporting channels"</li> </ul>	. 39 . 39 . 40 . 40 . 40 . 40 . 40 . 40 . 42 . 43 . 44 . 45
6.3.4.2 Submenu "Reporting sequence" (only master device)	49

6.4 6.5	<ul> <li>6.3.4.3 Buttons and function inputs</li> <li>6.3.4.4 Submenu "Relays" (function relays)</li> <li>6.3.4.5 Repeat Relays</li> <li>6.3.4.6 Submenu "LED color settings"</li> <li>6.3.5 Menu "Modbus"</li> <li>4 Main menu "Configuration"</li> <li>5 Main menu "Monitor"</li> </ul>	52 53 54 55 56 56 57 58
7 U:	sage and product life cycle	59
7. 7. 7. 7. 7. 7.	<ol> <li>Maintenance</li></ol>	59 59 59 60 60 60

# 1 Validity

The description applies to BSM modules with the following options:

59	В	х	х	х	х	С	R	х	х	0		
											Number of reporting channels	
		0	8								8 alarm inputs	
		1	6								16 alarm inputs	
		1	W								16 alarm inputs in wide housing (96 x 192 mm)	
		2	4								24 alarm inputs	
		3	2								32 alarm inputs	
		4	0								40 alarm inputs	
		4	8								48 alarm inputs	
											Operating voltage	
				1							24 V AC/DC	
				2							48 V AC/DC or 60 V DC	
				5							110 - 220 V AC/DC	
											Signal voltage	
					1						24 V AC/DC	
					3						48 - 60 V AC/DC	
					4						110 V AC/DC	
					Н						125 V AC/DC	
					5						220 V AC/DC	
					W						Wide range 50 - 250 V AC/DC	
											LED color adjustable (red, green, yellow, orange, blue, white)	
											Additional cards	
								0			none	
								R			8 relay outputs (only for 8 way annunciator)	
								R			16 relay outputs (only for 16 way annunciator)*	
								R			24 relay outputs (only for 24 way fault annunciator)	
								R			40 relay outputs (only for 40 way fault annunciator)	
											Redundant operating voltage	
									0		No additional power supply	
									1		24 - 60 V AC/DC	
									5		110 - 220 V AC/DC	

Table 1.1: Device variants of the BSM-C

\* 16s fault annunciator with integrated relay outputs only in wide housing (96 x 192 mm)

59	В	х	х	х	х	Ρ	R	х	х	х		
											Number of reporting channels	
		0	8								8 alarm inputs	
		1	6								16 alarm inputs	
		1	W								16 alarm inputs in wide housing (96 x 192 mm)	
		2	4								24 alarm inputs	
		3	2								32 alarm inputs	
		4	0								40 alarm inputs	
		4	8								48 alarm inputs	
											Operating voltage	
				1							24 V AC/DC	
				2							48 V AC/DC or 60 V DC	
				5							110 - 220 V AC/DC	
											Signal voltage	
					1						24 V AC/DC	
					3						48 - 60 V AC/DC	
					4						110 V AC/DC	
					Н						125 V AC/DC	
					5						220 V AC/DC	
					W						50 - 250 V AC/DC (wide range)	
											LED color adjustable (red, green, yellow, orange, blue, white)	
											Additional cards	
								0			none	
								R			3 relay outputs (only for 8 way annunciator)	
								R			16 relay outputs (only for 16 way annunciator)	
								R			24 relay outputs (only for 24 way annunciator)	
								R			40 relay outputs (only for 40 way annunciator)	
								1			8 relay outputs ( independent of the size of the annunciator ) *	
								2			16 relay outputs ( independent of the size of the annunciator ) * / **	
											Redundant operating voltage	
									0		No additional power supply	
									1		24 - 60 V AC/DC	
									5		110 - 220 V AC/DC	
											Interface Modbus RTU	
										0	none	
										М	Interface Modbus RTU switchable RS232 or RS485 **	

Table 1.2: Device variants of the BSM-P

\* 16 way fault annunciator with integrated relay outputs only in wide housing (96 x 192 mm)

\*\* Option is only available for BSM with 16 signal inputs in wide housing as well as with 24 – 48 alarms

All explanations on the parameterization software refer to version Parasoft-EES-SMT V 3.1.3.

# 2 General notes

# 2.1 Supplementary instructions

#### Note!

These instructions enable the safe and efficient handling of the fault indicators (hereinafter referred to as "BSM, fault indicator or device"). The instructions are an integral part of the device and must be kept in the immediate vicinity of the device and accessible to personnel at all times.



The personnel must have carefully read and understood these instructions before starting any work. The basic prerequisite for safe working is the observance of all safety instructions and handling instructions given in these instructions. In addition, the local accident prevention regulations and general safety regulations for the area of application of the device apply.

Illustrations in these instructions are for basic understanding and may deviate from the actual design.

# 2.2 Usage

These instructions are a prerequisite for the safe installation as well as the safe operation of the product and must be read and understood before installation.

## 2.3 Target group

These instructions are written for qualified personnel (electricians) who, due to their technical training, knowledge and experience as well as knowledge of the relevant standards and regulations, are able to carry out work on electrical systems and independently recognize and avoid possible dangers.

The electrician is specially trained for the work environment in which he works and knows the relevant standards and regulations.

#### 2.4 Explanation of symbols

#### Safety instructions

Safety instructions are identified in these instructions by symbols. The safety instructions are introduced by signal words which express the extent of the danger.



**Warning!** This combination of symbol and signal word indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



**Note!** This combination of symbol and signal word indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



#### **ENVIRONMENTAL PROTECTION!**

This combination of symbol and signal word indicates possible dangers for the environment.

# Tips and recommendations



This symbol highlights useful tips and recommendations as well as information for efficient and trouble-free operation.

## **Further markings**

The following labels are used in this manual to highlight instructions for action, results, listings, references, and other items:

Marking	Explanation
	Step-by-step instructions for action
	Results of action steps
	References to sections of this manual and to other applicable documents
	Listings without specified order
[Button]	Operating elements (e.g. buttons, switches), Display elements (e.g. signal lamps)
"Display"	Screen elements (e.g. buttons, Assignment of function buttons)

#### Important passage

This symbol indicates particularly important information.

#### **Cross reference**

This symbol refers to illustrations and other places in this documentation or to further literature.

# 2.5 Safety instructions

# 2.5.1 Intended use

The fault indicators are intended exclusively for the applications described in these instructions and may only be used under the conditions described in the chapter Technical data. Any use beyond the intended use or any other use is considered misuse.

#### WARNING!

#### Danger in case of misuse!

Incorrect use of the fault annunciator can lead to dangerous situations.

- Never use the devices in EX areas.
- Never use equipment in areas where there is a risk of interference without observing the special regulations for this.
- The devices must not be opened or improperly modified.

# 2.5.2 Storage of the manual



The instructions must be deposited within easy reach of the device and be accessible to personnel.

# 2.6 Customer service

For technical information please contact our customer service:

Address	Elektra Elektronik GmbH & Co Störcontroller KG
	Hummelbühl 7-7/1
	71522 Backnang
Phone	+ 49 (0) 7191/182-0
Fax	+49 (0) 7191/182-200
Email	info@ees-online.de
Internet	www.ees-online.de

In addition, we are always interested in information and experiences that result from the application and can be valuable for the improvement of our products.

# 2.7 Copyright, trademarks, GNU licenses

# Copyright

This manual is protected by copyright.

The transfer of this manual to third parties, duplications of any kind and in any form - including excerpts - as well as the utilization and/or communication of the contents are not permitted without the written consent of Elektra Elektronik GmbH & Co. Störcontroller KG (hereinafter referred to as the "manufacturer") except for internal purposes. Violations will result in liability for damages.

The manufacturer reserves the right to assert additional claims.

The copyright is held by the manufacturer.

© Elektra Elektronik GmbH & Co Störcontroller KG 2020

#### Usage of open source software

Our firmware contains partial source code produced under the GNU Public License (GPL) by third parties and published for use by anyone. This software is under special open source software licenses and third party copyright. In principle, each customer may freely use the open source software in accordance with the license terms of the respective manufacturers. The rights of the customer to use this software beyond the purpose of our product are regulated in detail by the respective open source software, as provided for in the respective valid license, beyond the purpose for which the software serves in our product.

The use of the open source software used is free of charge. We do not charge a usage fee or other comparable fees for the use of the open source software contained in our products.

The GPL code used in our product is published without warranty and is subject to the copyright of the corresponding author. If programs contained in our products are subject to the GNU General Public License (GPL), GNU Lesser General Public License (LGPL), the Clarified Artistic License or any other open source software license that stipulates that the source code must be made available and the software has not already been supplied with our product on a data carrier in the source code, we will send this at any time on request. If the sending on a data carrier is requested, the sending takes place against payment of an expense lump sum at a value of  $10,00 \in$ . Requests are to be directed to our customer service, stating the article and serial number.

Email:	info@ees-online.de
Phone:	+ 49 (0) 7191/182-0
Fax:	+49 (0) 7191/182-200

# **3 Functional description**

# 3.1 Basic structure of the BSM

The annunciators are manufactured in 2 performance classes.

- BSM-C: Basic version configurable via DIP switch
- BSM-P: Software parameterizable version

The fault indicators are used to record and display alarms that are provided via galvanic inputs. The alarms are processed and displayed according to the parameterized fault alarm sequence. In addition, the alarms can be forwarded to higher-level systems via the optionally available Modbus interface.

The fault indicators are offered with 8, 16, 24, 32, 40 or 48 signal inputs. The signal inputs are combined in groups of 8 alarms each. The closed front surface contains 4 buttons, 3 status LEDs, one RGB LED for each alarm with which the 6 color variants (red, green, yellow, blue, orange and white) can be parameterized and insertion pockets for the labeling strips.

The BSM-P has an internal horn. With both versions of the BSM (BSM-C and BSM-P), an external horn can be controlled via a function relay.

The two function inputs are used according to the selected signal sequence (e.g. external acknowledgement). The integrated function relays are designed as changeover contacts. They realize alarm-specific functions (e.g. collective alarm and control of an external horn) as well as the signaling of a malfunction by a live contact.

All fault indicators of the BSM series have a **status memory in case of power failure**. If the supply voltage fails, all visual and acoustic signals are switched off and the relays drop out. During the power failure, no new alarms are registered and acknowledgements are not possible. After voltage recovery, all states are immediately resumed and the fault annunciator is wide for operating actions and new alarms.

The fault indicators have a hardware watchdog and software monitoring. The fault-free function is signaled by LED and relay contact (live contact).

The BSM-P can be parameterized via a parameterization program and the USB parameterization interface. The most common fault alarm sequences, input processing, collective alarm formations and horn controls can be set, and the mode of operation of the buttons, function inputs and relay outputs can be defined. A detailed description of the parameterization can be found in the chapter "Parameterization". Customer-specific fault reporting sequences can be implemented ex works if required.

The fault annunciator has USB and CAN bus, and optionally an RS232/485 interface, whose function and use are described in the following sections.

Many energy plants operate unmanned at times and only in the event of maintenance or a fault is someone on site. For this purpose, two special functions have been integrated in the fault indicators, which are signaled as an additional operating mode by green flashing of the alive LED.

#### • Mute function

In the "Silent" operating mode, the horn is not triggered or is automatically acknowledged after a parameterizable time. The function is switched on or off with a button parameterized for this purpose. The operating mode can also be activated via a parameterizable function input. In this case, the "Silent" mode is only active as long as a voltage is present at the input.

#### Unmanned

The fault indicators can be switched between the operating modes "manned station" and "unmanned station". In the "unmanned station" state, there is no visual or audible output of pending alarms. The internal alarm processing and, if necessary, the control of relays or the output via an interface remain active. Alarm acknowledgement at the fault annunciator is deactivated.

In order to not only display the individual fault alarms via LED, but also to forward them via relay contact in input or output parallel (1:1 relay), two methods can be used:

- 1. Integration of additional relay cards (8 NO contacts each) for use as 1:1 outputs. These relays can be freely assigned in the parameterizable fault indicators. The relay cards are optional and must be taken into account when ordering.
- Connection of external relay modules to the CAN bus socket. For further information on the expansion modules, please refer to the separate data sheet MSM-EM-DB-UK.

For further information on the integrated fault reporting sequences, please refer to the separate documentation "Reporting sequences of the EES fault indicators".

# 3.2 Internal Relay cards (optional)

The optionally integrable relay cards (8 NO contacts each) are independent of the 4 function relays of the fault annunciator and can be used for the following functions:

- 1. Single or output-parallel multiplication and forwarding of individual alarms directly in the fault annunciator without connection of external relay modules
- 2. Output of collective alarms and horn control

Each of the 8 relays on a plug-in card has a common root. With the BSM-P, control and mode of operation can be individually adapted with the aid of the parameterization program, e.g. inversion of the signals. With the BSM-C, these functions are fixed at the factory (see section <u>Configuration</u>).

# 3.3 Redundant power supply (optional)

Independent of the primary supply voltage, a second, redundant power supply unit can be integrated into the fault annunciator. Two voltage variants are available for this purpose:

- 24 60 V AC/DC
- 110 220 V AC/DC

The voltage level of the redundant power supply can be selected independently of the voltage level of the primary power supply. Both the primary and the redundant power supply unit are included in the self-monitoring of the fault annunciator and faults are output via the alive relay. In addition, the presence of the supply voltage on both power supply units is signaled via an LED on the front and rear of the fault annunciator.

# 3.4 Cascading of several fault indicators

With the cascading function, one BSM or one USM (universal fault monitor) and up to 3 BSMs (BSM-C or BSM-P) can be combined to form a fault monitoring system. In this case, the devices are connected via the system bus provided at the CAN bus sockets using network cables (patch cables). A fault annunciator operates as a "master" and the connected BSMs as "slaves". Thus, systems with a maximum of 192 signal inputs (4\*48) can be realized. Systems formed in this way behave like a (virtual) fault annunciator with common annunciation processing (annunciation sequence, collective annunciation formation, horn control). The alarms of the entire system can be accessed via the optional Modbus interface of the master annunciator.

External MSM relay expansion modules cannot be connected when using fault annunciator cascades.



The parameterization of fault alarm cascades takes place completely in the master fault annunciator and is then automatically distributed to the slave fault annunciators. For information on the USM, please refer to the separate operating instructions MSM-USM2G-BA-UK.



Fig. 3.1: Basic structure of a cascaded annunciator system

# 3.5 Interfaces

The BSM has the following interfaces:

- 2 x CAN-Bus (System bus for connecting expansion modules or setting up fault alarm cascades - see also section <u>Cascading</u>)
- 1 x USB-B (factory interface) Parameterization interface (only BSM-P)
- 1 x COM RS232/485 / pluggable terminal as Modbus RTU interface (optionally only BSM-P)

# 3.6 Labeling

The BSM is labeled using labeling strips that are slid under the cover foil after the front frame has been removed. To do this, use both thumbs to lift the frame out of the clamp from behind at one corner, then lift it out further along the edges and remove it carefully.



Fig. 3.2: Removing the cover frame



Fig. 3.3: Inserting the labeling strips under the cover foil

The labeling strips with the alarm texts and button designations can be printed directly from the parameterization interface for the BSM-P. Templates in Word format are available for manual creation of the labeling strips for BSM-C and BSM-P.

# 3.7 Control lights, buttons and connectors

Alarm /Meldung X14.1	Alarm /Meldung X12.1	Alarm /Meldung X10.1	CES
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	
X14.2	X12.2	X10.2	
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	
X14.3	X12.3	X10.3	
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	⊗√
X14.5	X12.5	X10.5	
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	
X14.6	X12.6	X10.6	
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	00 F.T.
X14.7	X12.7	X10.7	
Alarm /Meldung	Alarm /Meldung	Alarm /Meldung	
X14.8	X12.8	X10.8	

Fig. 3.4: Front view of the BSM24

- Alarm lights (Function depends on the parameterized reporting sequence) [1]
- [2] [3] Buttons 1 ... 4 (Function depends on parameterization)
- Control lights

ate"
- No error, no alternative operating state
- No supply voltage or device defective
- Error (see section Diagnostic functions)
- Signaling of an alternative operating state
(see table below)
ge 1
<ul> <li>No supply voltage 1 and 2</li> </ul>
<ul> <li>Error supply voltage 1</li> </ul>
- Supply voltage 1 error-free
ge 2 (redundant supply)
- Option redundant supply voltage not integrated
- Error supply voltage 2
- Supply voltage 2 error-free

Flashing sequence	Alternative operating state	Note
long – short	Mute function activated	As long as the operating mode is activated, the horn is not triggered or automatically acknowledged after the parameterized time.
long – long – short	Unmanned mode activated	As long as the operating mode is active, there is no visual or audible output of pending alarms. The internal alarm processing and, if necessary, the control of relays or the output of alarms via an interface remain active. Alarm acknowledgement at the fault annunciator is deactivated.

Table 3.1: Alternative operating states of the BSM are indicated by the green flashing of the "OK" control light.



During the initialization process of the fault annunciator after the restart, the three control lights "OK", "S1" and "S2" light up green several times in a row.



The illustration of the BSM with 24 signal channels is given here only as an example to clarify the principle. The number of signal channels and the LED colors of the signal lamps may vary depending on the configuration and size of the annunciator.



Fig. 3.5: Back view of the BSM24-P with Modbus

- [4] Terminals Supply voltage 1 (green LED indicates voltage present)
- [5] Terminals Supply voltage 2 (redundant supply voltage optional)
- (green LED indicates voltage present)
- [6] Terminals Function relay 1 4
- [7] Terminals alarm inputs
- [8] Terminals relay cards (optional)
- [9] Terminals function inputs 1 and 2
- [10] CAN-Bus inputs (System bus / RJ45)
- [11] Control lights "communication"
  - red Tx serial interface
    - green Rx serial interface
    - yellow Can-Bus
- [12] USB-B (factory interface), Service, diagnostics and parameterization interface
   [13] Terminals Modbus-RTU interface (RS232/485) (only optional with BSM-P)



On the BSM 08, terminal X11 (function inputs) is not located under terminal X12, but under terminal X10.



The DIP switches S30, S32 and S34 are only present when the optional relay cards are inserted.

# 3.8 Diagnostic functions

Diagnostic information is available for monitoring and assessing system functions by signaling errors via LED and relay contacts.

# 3.8.1 Control light "Operating mode" and Alive Relay

The "Operating status" indicator light provides information on the current status of the station or system:

Steady light green

- No error

Green flashing •

- Initialization process or alternative operating mode (see section Control lights, buttons, connections)

Red flashing

- Error (see section "Error list") - No power supply
- Off

An error code can be derived from the blink sequence and the associated error can be inferred. A flashing sequence consists of:

- Number of long flashes  $\rightarrow$  1st digit of the error code
- Number of short flashed  $\rightarrow$  2nd digit of the error code •
- Pause •

Example: long, short, short, pause = Error code 12



If several errors occur simultaneously, the one with the highest priority is always displayed.

In addition to the "Operating mode" indicator lamp, the live relay with changeover contact signals the status of the fault annunciator.

**Terminal X2** Contact 11 / 10 closed - Power failure or error ( - Error codes) Contact 11 / 12 closed - No error

# 3.8.2 Error codes

The error codes listed in the following table correspond to the flashing sequence of the "Operating status" indicator lamp of the BSM.

Example:

Error 15 - Communication in the fault annunciating cascade disturbed Blinking sequence of the indicator lamp - long, short, short, short, short, short, Pause

The following table lists the error codes of the BSM:

Error code	Error	Note
11	Internal error	If the error occurs again after restarting the device, send the
12	Internal error	device to EES for inspection.
13	Overflow alarm buffer	After the occurrence of an alarm surge, intermediate states of alarms may have been lost. The final states are valid.
14	Relay cards	If the error occurs again after restarting the device, send the device to EES for inspection.
15	Communication in the fault annunciating cascade disturbed	This error can occur with fault annunciating cascades. It is displayed when the connection between the master (BSM or USM) and at least one configured slave BSM is interrupted. Please check the configuration of the slave addresses on the BSM (DIP switch combination S1) and the connection cables.
17	Operating voltage 1	Fault of a power supply unit - only for fault indicators with
18	Operating voltage 2	redundant power supply
19	Configuration inconsistent	The configuration entered does not match the device (e.g. BSM 08 and BSM 16).
33	Parameter file missing	Restore factory setting via parameterization program, then perform parameterization again or import. Contact customer service if the error persists.
34	Imported configuration is faulty	Import correct file or restore factory setting via parameterization program.

Table 3.2: Error codes of the BSM

# 3.9 Terminal assignments



Fig. 3.6: Terminal assignment BSM

# Detailed terminal assignment

#### Alarm inputs (X10, X12, X14, X16, X18, X20)



Fig. 3.7: Terminal assignment of the alarm inputs

Output relays (X30, X32, X34, X36, X38, X40)



Fig. 3.8: Terminal assignment of the output relays

# Functional inputs (X11)

F1 —	01
F2 —	02
- / N —	03

Fig. 3.9: Terminal assignment of the functional inputs

# 3.10 Front and back view of the BSM

The following pages show the front and rear views of the fault indicators. Please note the arrangement of the terminals of the signal inputs and their assignment to the displays in the front. The devices are shown in each case with the maximum configuration, i.e. all options. For devices that do not have these options, the corresponding terminals are omitted.

# 3.10.1 BSM 08



Fig. 3.10: Front and back view of the BSM 08



# 3.10.2 BSM 16

Fig. 3.11: Front and back view of the BSM 16 in housing 96 x 96





Fig. 3.12: Front view of the BSM 16W in wide housing 96 x 192



Fig. 3.13: Back view of the BSM 16W in wide housing 96 x 192

# 3.10.4 BSM 24



Fig. 3.14: Front view of the BSM 24



Fig. 3.15: Back view of the BSM 24

# 3.10.5 BSM 32



Fig. 3.16: Front view of the BSM 32



Fig. 3.17: Back view of the BSM 32

# 3.10.6 BSM 40

Alarm/Meldung X18.1	Alarm/Meldung X16.1	Alarm/Meldung X14.1	Alarm/Meldung X12.1	Alarm/Meldung X10.1	Ces
Alarm/Meldung X18.2	Alarm/Meldung X16.2	Alarm/Meldung X14.2	Alarm/Meldung X12.2	Alarm/Meldung X10.2	
Alarm/Meldung X18.3	Alarm/Meldung X16.3	Alarm/Meldung X14.3	Alarm/Meldung X12.3	Alarm/Meldung X10.3	
Alarm/Meldung X18.4	Alarm/Meldung X16.4	Alarm/Meldung X14.4	Alarm/Meldung X12.4	Alarm/Meldung X10.4	_ ⊗√
Alarm/Meldung X18.5	Alarm/Meldung X16.5	Alarm/Meldung X14.5	Alarm/Meldung X12.5	Alarm/Meldung X10.5	
Alarm/Meldung X18.6	Alarm/Meldung X16.6	Alarm/Meldung X14.6	Alarm/Meldung X12.6	Alarm/Meldung X10.6	⊗LTest
Alarm/Meldung X18.7	Alarm/Meldung X16.7	Alarm/Meldung X14.7	Alarm/Meldung X12.7	Alarm/Meldung X10.7	00 F.T.
Alarm/Meldung X18.8	Alarm/Meldung X16.8	Alarm/Meldung X14.8	Alarm/Meldung X12.8	Alarm/Meldung X10.8	

Fig. 3.18: Front view of the BSM 40



Fig. 3.19: Back view of the BSM 40

# 3.10.7 BSM 48



Fig. 3.20: Front view of the BSM 48



Fig. 3.21: Back view of the BSM 48

# 3.11 Input and signal light assignment

The first input of the input terminal with the highest designation is always the first alarm at the top left of the front panel display. In the following example, this is X14.1. The other assignments of the input terminals are as shown in the individual alarm texts on the front panel in the drawing below.





Fig. 3.22: Assignment between signal input and LED display using the example of a BSM 24

# 3.12 Technical data

# Supply voltage U<sub>Sup</sub>

Key	Rated voltage	Voltage range
1	24 V AC/DC	1937 V DC or 1426 V AC
2	48 V AC/DC or 60 V DC	3773 V DC or 2651 V AC
5	110 V AC/DC or 220 V AC/DC	100370 V DC or 85264 V AC

Table 3.3: Supply voltage keys – BSM

## Signal voltage U<sub>Sig</sub>

		Threshold for alarm		Maximum	Input current per
Key	Rated voltage [V AC/DC]	Inactive [V AC/DC]	Active [V AC/DC]	permitted voltage [V AC/DC]	input @ rated voltage [mA]
1	24	11	15	50	2,3
2	48	17	25	75	2,1
3	60	17	25	75	2,7
4	110	35	50	150	1,6
Н	125	35	50	150	1,8
5	220	100	140	260	1,2
W	50 - 250	25	45	250	1,6

Table 3.4: Signal voltage keys – BSM



The voltage  $U_{\text{Sig}}$  is valid for signal inputs and function inputs.

If not otherwise specified the given information for alternating voltage are effective values and refer to a sinusoidal alternating voltage with a frequency of 50/60 Hz.

#### **Power consumption**

Number of	Power consumption [W]		
channels	Without integrated repeat relays	With integrated repeat relays	
8	< 4	< 6	
16	< 5	< 9	
24	< 5	< 13	
32	< 6	< 11*	
40	< 7	< 19	
48	< 8	< 13*	

Table 3.5: Power consumption – BSM

\* The power consumtion of 32- and 48-way annunciators with integrated repeat relays refers to a maximum number of 2 relay cards (16 relays).

100 ms
5 ms
100 ms
adjustable (0 1000 ms), Factory setting 5 ms
adjustable (5 ms 9 h), Factory setting 100 ms
2 Hz
),5 Hz
24 250 V AC 2 A; 110 V DC 0,5 A; 220 V DC 0,3 A

#### Mechanical data

Type BSM/USM	Front frame H x B x T [mm]	Panel cut-out [mm]	Depth with front frame and terminals [mm]	Weight [kg]
08	96 x 96 x 8	92 x 92	100	approx. 0,40
16	96 x 96 x 8	92 x 92	100	approx. 0,45
16 in wide housing 24 32	96 x 192 x 8	92 x 186	100	approx. 0,70
40 48	96 x 287 x 8	92 x 282	100	approx. 1,00

Table 3.6: Dimensions – BSM

<b>Mounting</b> Required installation depth Minimum horizontal gap	panel mounting 120 mm
Between 2 devices Connection terminal Wire cross section rigid or flexible	15 mm pluggable
Without wire sleeves With wire sleeves	0,2 2,5 mm <sup>2</sup> 0,25 2,5 mm <sup>2</sup>
Ambient environment	
Operating ambient temperature	-20°C +60°C
Duty cycle	100 %
Protection class at the front	IP 54
Protection class at the rear	IP 20
Humidity	75% r.h. max. on average over the year;
	condensation during operation not permitted [Test:40°C, $93\%$ r.h. > 4 days]
Electrical data	
AC voltage resistance	
CAN-Bus and USB	500 V / 50 Hz 1 min
Digital inputs	4 kV AC / 50 Hz 1 min
	4 KV AC / 50 HZ I MIN 2 0 kV AC / 50 Hz 1 min
Supply (110 / $230$ × AC/DC) Supply (24 / 48 × AC/DC)	1.0 kV AC / 50 Hz 1 min
	.,

500 V / 50 Hz 1 min

Relay outputs against each other

Surge voltage resistance	
RS232/RS485 against	
Digital inputs	2,5 KV ; 1,2 / 50 µS; 0,5 J; acc. 10 IEC60255-27
Relay outputs	$2,5 \text{ kV}$ ; $1,2/50 \mu\text{s}$ ; $0,5 J$ ; acc. to IEC60255-27
Supply	2,5 kV ; 1,2 / 50 $\mu$ s; 0,5 J; acc. to IEC60255-27
Relay outputs against each other	500 V ; 1,2 / 50 μs; 0,5 J; acc. to IEC60255-27
Dielectric strength Electromagnetic compatibility	
Noise immunity acc. to	DIN FN 61000-4-2
	DIN EN 61000-4-3
	DIN EN 61000-4-4
	DIN EN 61000-4-5
	DIN EN 61000-4-6
	DIN EN 61000-4-12
Noise irradiation acc. to	DIN EN 61000-3-3
	DIN EN 55011



The devices are designed and manufactured for industrial applications according to EMC standard.



## Note!

Incorrect use (e.g. deviations of temperature, supply voltage or signal voltage from the specified values) can cause damage to the devices.

Subject to technical changes without prior notice

# 4 Mounting and installation



# **Warning!** The devices may only be installed by qualified personnel (electricians) with the operating voltage switched off.

- 1. Unpack all modules of the delivery and check for possible transport damages. Report any transport damages to the responsible forwarding agent immediately. Please verify the integrity of the delivery according to the shipping documents.
- 2. Insert the annunciator into the prepared panel cut-out and fix it with the fasteners at the side of the device.
- 3. Connect input and output lines.



The length of the wires of the in- and outputs should not exceed 3 m.

- 4. For a cascaded annunciator system, connect slaves according to steps 2 and 3 and connect the cascaded annunciators to each other by means of a patch cable through the CAN-Bus-interfaces (terminals X7 / X8 at the BSM and terminal X7 at the USM).
- 5. Connect the power supply and activate power supply.



The length of the power supply wires should not exceed 10 m.

6. Configure the fault annunciator (see section Configuration.)

If a BSM-P is used, apply parameterization. (see section <u>Parameterization</u>)

7. After switching on, the fault annunciator requires about 30 s for the system test and initialization, which is completed with alternate green flashing of the "OK", "S1" and "S2" watchdog-LEDs.

Watchdog-LED "Self-monitoring" is in steady light – the fault annunciator is operational.

Watchdog-LED is flashing (see section Diagnosis.)



# **5** Configuration

For both BSM-C and BSM-P some main settings of the annunciator can be defined by configuration through DIP-switches. If further settings are required additional parameterization by software is possible for the BSM-P (see section <u>Parameterization</u>).



To apply the DIP-switch settings to the annunciator, DIP-switch S1/4 has to be set to ON. If the additional options of the software parameterization are to be used for the BSM-P, the DIP-switch S1/4 has to be set to OFF (default setting).

# 5.1 Cascading functionality (DIP-switch combination S1)

Switch	Function	Setting			Default setting
S1/4	Definition of the functionality as per DIP-switch (configuration) or parameterization (this definition is valid for all settings of the annunciator)	OFF – F ON – C	Paramet (softwa onfigura (DIP-sw	erization re) tion <i>v</i> itch)	OFF - Parameterization
	S1/1 = OFF (device is Master)	S1/3	S1/2	Slave	OFF, OFF
S1/2 and	<ul> <li>Number of connected slaves</li> </ul>	OFF	OFF	none	No connected slaves
S1/3 anu S1/2	or	OFF	ON	1	or no slave address
31/2	S1/1 = ON (device is Slave)	ON	OFF	2	
	- Slave-address	ON	ON	3	
S1/1	Master or Slave	OFF - N ON - S	laster Slave		OFF - Master

Table 5.1: Assignment of DIP-switch combination S1



If the BSM is not part of a cascaded annunciator system, DIP-switches S1/1 - S1/3 are to be set to OFF (default setting).

# 5.2 Alarm group related DIP-switch combinations (S10 – S20)

The DIP-switches 1 and 2 of these DIP-switch combinations always affect the respective alarm group (8 channels) which is assigned to the respective terminals.

Dip-switch	Terminal	
S10	X10	
S12	X12	
S14	X14	
S16	X16	
S18	X18	
S20	X20	

Í

The functions of the switches 3 and 4 are set on one DIPswitch combination for the whole device. For the BSM08 this is the combination S10 and for all other BSM it is the combination S12.

Table 5.2: Assignment of the DIP-switch combinations to the reporting channels (input terminals)

# Configuration

Switch	Function	Meaning	Factory setting
S /A	Reporting sequence with setting of	OFF - New value sequence*	OFF – New value
0./4	switch S./2 OFF (fault alarm)	ON - First-Up sequence*	sequence
S /2	Horn control for follow-up alarm	OFF - Horn is activated again	OFF
3./3		ON - Horn is not	Horn is activated
		recontrollable	again
	Signaling of the signaling group	OFF – Fault alarm	OFF – Fault alarm
S /2	(8 channels)	(red flashing light)	
5./2		ON - Operating alarm	
		(green steady light)	
C /1	Normally open / Normally closed	OFF - Normally open	OFF – Normally
3./1	principle of the group (8 channels)	ON - Normally closed	open

Table 5.3: Assignment DIP switch combination S10 – S20

- \* The detailed designations of the signal sequences are as follows
  - New value with 1-frequency flashing light and single acknowledgement or
  - First-Up with 1-frequency flashing light and single acknowledgement.



For more detailed information on the fault reporting sequences, please refer to the separate document describing the SM-MA-FB-DE fault reporting sequences.

# 5.3 Configuration of the relay groups

The DIP-switches of the relay groups (S30 – S38) if available, have no function in these annunciator variants.

The relay groups are factory set as follows:

- Relays are assigned 1:1 to the respective inputs.
- If only 1 or 2 relay groups (8 relays each) are integrated (e.g. BSM48), these are assigned to the first or the first two alarm groups (8 inputs each).
- The relays are triggered input parallel.
- The relays are not inverted.

#### 5.4 Color configuration of the alarm lights through key combinations

The display of the alarms of the BSM is done via one RGB LED per channel. These RGB LEDs can be used to set the 6 color variants (red, green, yellow, blue, orange or white). The setting of the color variants of each LED can be done via key combinations. With the BSM-P, parameterization with the PC program (see section <u>Parameterization</u>) is more convenient.



The setting of the LED colors via key combination is only available from firmware version 10.0.0.

Depending on the alarm sequence and the status of the alarm of the respective channel, the abovementioned 6 colors or the LED state "Off" can be set:

Reporting procedure	Signalling state of the channel	Factory setting of the LED colors
	Alarm pending (flashing state LED "On")	Red
	Alarm pending (flashing state LED "Off")	LED "Off"
Fault signal	Alarm is pending and has been acknowledged (steady light)	Red
	Alarm gone and acknowledged (corresponds to LED off)	LED "Off"
Operating signal	Alarm is on (steady light)	"Green"
Operating signal	Alarm has gone (corresponds to LED off)	LED "Off"

Table 5.4: Setting options of the color configuration



In the standard fault alarm sequence, the LED flashes e.g. with red color "On" and "Off". For special sequences, a different color can be set for the "Off" state of the LED. The color of the LED then changes e.g. between red and green.



Fig. 5.1: Buttons as an example on the BSM 08

The 4 buttons in the front of the BSM-C are used for configuration. The following settings can be made for each channel and thus each LED:

Parameter	Selection option	Example
	State 1 Alarm active flashing on	Fault alarm with 2-frequency flashing light new unacknowledged alarm state "On" of the flashing LED
	State 2 Alarm active flashing off	Fault alarm with 2-frequency flashing light new unacknowledged alarm State "Off" of the flashing LED (normally off, i.e. black)
Reporting status	State 3 Alarm active, acknowledged	Fault alarm with 2-frequency flashing light acknowledged alarm, which is still active color of the steady light
	State 4 Alarm off, acknowledged	Fault alarm with 2-frequency flashing light acknowledged alarm, which is no longer active color of the state off (normally off, so black)
	State 5 Operating alarm on	Steady light green
	State 6 Operating alarm off	LED off (also black)
Color setting	Red, green, yellow, blue, orange, white, black (off)	Flashing fault alarm red or operating alarm steady light green
Channel	1 48	Selection of 1 or more channels to which these settings should apply.

Table 5.5: LED color setting parameters

# Configuration

1. **Switch on the device** and wait until normal fault indication mode is reached (OK LED lights up in green continuous light).

#### 2. Activate configuration mode

Keep buttons T1 and T4 – or else, up from firmware 10.3, T2, T3 and T4 together – pressed for approx. 2 seconds! An acoustic signal sounds, the OK LED flashes red/green. The first LED at the top left flashes in the currently set color. The BSM is in configuration mode.



If the BSM is operated as a slave in a cascaded annunciator system (see also section <u>Cascading</u>), the configuration mode cannot be switched on. In this case, set switch "S1/1" to "Off" - master during configuration of the LED colors.

#### 3. Select state of alarm

Select the desired signal state (see table above) by pressing the "T1" key several times! To confirm, depending on the set status, the LEDs 1 to 6 light up briefly in white (e.g. status 5 - the LEDs 1 to 5 light up briefly).

#### 4. Selection of the desired channel

By pressing the "T3" or "T4" key several times, the channel (1 ... 48) can be selected to which a color is to be assigned in the next step for the alarm state selected in step 3. Key "T3" decreases and "T4" increases the channel number.



By holding down "T3" or "T4" while pressing the other key, several channels can be selected simultaneously.



The selected LEDs light up permanently in the currently set colors.

#### 5. Select color

Select a color by pressing the "T2" key several times. The LEDs of the selected channels light up in the selected color.



The color black (LED off) is displayed flashing gray.

#### 6. Make further settings

If desired, make further settings in this order alarm state, channel setting and color setting.

#### 7. Finish configuration

Keep keys T1 and T4 pressed for 3 s. The configuration is saved, all LEDs go out and the fault annunciator performs a restart.



Fig. 5.2: Schematic representation of LED color setting by key combination

# 5.5 Default settings

- LED-colour
- Function input 1
- Function input 2
- Button 1
- Button 2
- Button 3
- Button 4
- Function relay 1
- Function relay 2
- Function relay 3
- Function relay 4
- Collective report
- Horn
- Horn lock

- red for fault signalling and green for operation indication
- horn acknowledgement
- acknowledgement
- horn acknowledgement
- acknowledgement
- lamp test
- not assigned
- collective report 1
- not assigned
- external horn
- live-contact
- static / output parallel
- retriggerable by subsequent alarm, manual acknowledgement
- none

# **6** Parameterization

Alternatively to configuration by DIP-switches the BSM-P can be parameterised by software. To parameterise the device the service and diagnosis interface USB-B (terminal X9) of the BSM-P has to be connected to the PC.

#### System requirements

- Windows 7 or Windows 10
- Internet browser with activated Javascript We recommend to use Mozilla Firefox from version 40 or Internet Explorer from version 11. When using other internet browsers the functionality of the parameterization software might be
- limited. Recommended monitor resolution from 1280 x 800

# Installation

The installation starts with the execution of the file "EES-SMT-Parasoft V3.X.X.exe". X.X in this case are replacement markers for the respectively current software version. During installation, 2 Visual C++ packets are installed additionally, in case they are not yet available on the PC. This may require a restart of the PC.

A total of 6 programs are installed:

CDM v2.12.28 WHQL Certified	- Driver installation program for the FTDI USB serial adapter used in the BSM, is normally executed (if not deselected) during the installation of the parameterization software
EES-SMP-Parasoft v3.1.3	- Parameterization software
Change-Default-Port-8080	- Allows to change the default port of the Windows web server from (80) to 8080 if another program on your PC occupies it
EES-SMP-Parasoft v3.1.3 Port 8080	- Calls the parameterization software after execution of Change-Default-Port-8080 via port 8080
Reset-IIS-Server	- Restarts the web server (necessary if a logon is login is no longer possible due to an error).
Uninstall EES-SMT-Parasoft v3.1.3	- Uninstalling all program components installed with the EES- SMP program components

#### Start of the software EES-SMT-Parasoft

Please launch the program "EES SMT-Parasoft V3.X.X" in the start menu or from the icon on the Desktop.

admin

admin

The login screen will automatically be opened in the default browser of the PC.



Fig. 6.1 Login



The passwords can be changed on the "System" dialog page.

If you have not yet connected a fault annunciator, you will be prompted after correct login either to connect a device and to identify and select it using the "Identify device" button or, if you do not yet have the device available, to select a device type manually (see also section <u>New / adapt submenu</u>).

ew/adapt Export/Import			
New device Master device	Slave device: 1	Slave device: 2	Slave device: 3
BSM/WAP-P USM/WAP-K 32 Inputs	16 Inputs + 16 Relays •	24 Inputs 👻	☐ 32 Inputs + 08 Relays ◆

Fig. 6.2 New/Customize submenu in the menu "Device administration"

Aside from the EES logo, you can navigate among the 5 main menus

- Language
- Information
- Parameter
- Configuration
- Monitor

and the symbol bar consisting of 5 buttons

H ± 🗇 O C•

The buttons have the following meaning:

Adopt configuration

Saving the changed parameters of the currently edited device in the working memory of the PC.

• Adopt all 4 configurations

With this button the parameters of all devices (Master device and the possibly connected extensions (slave device 1 ... 3) are stored in the working memory of the PC.

Please note that the parameterization needs to be saved either

- with the menu command "Write configuration/parameters to device" in the device
- or with "Parameter/System/Export/Import" in a file on the computer.

Otherwise, the current changes will be discarded once you log out.

• Dismiss configuration

Discard all changes made in the session (since the last "Accept configuration").

- Version
   Display of the version number of the para
- Display of the version number of the parameterization program • Sign out
  - Sign out of the program

Please always end the parameterization with the "Logout" function and not by closing the browser window. Otherwise, the current user will only be logged out automatically after a few minutes. Since only one "admin" can be logged in at a time, access is only possible again after the automatic logout or the restart of the PC. When logging off without first accepting the configuration, the currently entered parameters are discarded.

Below the main menu bar, the current menu path and the user name are visible.

♠ / Parameter / System / Master-Gerät

In this tutorial we will explain the individual menus in the order in which they appear in the menu bar.

Some dialog pages are structured in the form of tabs and contain additional buttons. The function of these elements is explained in the description of the respective pages.

Reporting channel	Reporting sequence	Buttons & Function inputs	Relays	LED-color selection
Fig. 6 3: Card tab on the	Master Device dialog page			

Fig. 6.3: Card tab on the Master Device dialog page

When switching between the individual menus or tabs, the changes are temporarily saved but not yet adopted in the current configuration of the fault annunciator. This is only done with the "Accept configuration" action.

#### 6.1 Main menu "Language"

In this menu, the web interface of the parameterization can be switched between the two languages German and English.

# 6.2 Main menu "Information"

Geräteinformation EES-SMT-Parasoft Version: v3.1.3 EES-SMT-Parasoft-WIN7\_FCGI Version: v3.3.1 EES-SMT-Parasoft-PortHandler Version: v2.3.1 EES-SMT-Parasoft-ExcelXmlConv Version: v3.2.0 EES-SMT-Parasoft-WebGUI Version: v3.1.3 ######### connected devices ######### Device0: BSM-P, 24 inputs, 16 relays, RGB LEDs, Mute, Unmanned, Unassigned Reports Firmware version: 14729000.010.000 PowerSupply: single v2.00 Device1: -- uninstalled --Device2: -- uninstalled --Device3: -- uninstalled --######## interfaces ######## Ausführen, um Geräteinformationen zu laden: It Gerät identifizieren

Fig. 6.4: Main menu "Information"

The dialog page contains version information of the parameterization software and the connected devices as well as information about the options of the fault indicators.

# 6.3 Main menu "Parameter"



The Parameter main menu has several submenus and one menu for each registered fault annunciator. In cascades, this can be 1 master device and a maximum of 3 slave devices.

Fig. 6.5: Open main menu "Parameter"

# 6.3.1 Serial interface

-

## Serial interface

The parameterization interface on the PC is selected in the "Serial interface" main menu. The selection is only available if a BSM is already connected.



COM-Ports

When a BSM is connected to the PC for the first time, the associated driver is automatically loaded by Windows. If no interface can be selected afterwards, it may be necessary to restart the PC. If the selection of the interface is still not available, the driver was not loaded correctly. In this case, please contact our service team. We will be happy to provide you with this driver separately.

# 6.3.2 Menu "Device administration"

After clicking on the "Device administration" menu in the "Parameters" main menu, a new dialog box opens with which a fault indicator can be added or removed or the parameterization of the devices can be exported or imported.

#### 6.3.2.1 Submenu "New/adapt"

With the cascading function, a fault alarm system can be formed from one BSM or USM and up to 3 BSM-C or BSM-P, which has a common alarm processing (reporting sequence, collective alarm formation and horn control).

The individual devices communicate with each other via the integrated system bus, which is provided via the CAN bus interfaces. For this purpose, the devices are connected with network cables (patch cables). One annunciator works as a "master" and the other connected annunciators as "slaves". Thus systems with up to 192 alarm inputs (4\*48) can be realized. External MSM relay expansion modules cannot be connected when using fault annunciator cascades.



The parameterization of fault alarm cascades takes place completely in the master fault annunciator and is then automatically distributed to the slave fault annunciators.



Fig. 6.6: Example of a fault alarm cascade

Please note that the slave devices must be configured as slave via DIP switch and the corresponding slave addresses (1 - 3) must be set.

adapt Export/Import			
Vew device Master device	Slave device: 1	Slave device: 2	Slave device: 3
BSM/WAP-P USM/WAP-K 32 Inputs	16 inputs + 16 Relays •	24 inputs 👻	a 32 Inputs + 08 Relays →

Fig. 6.7: Submenu "New/adapt"

You have the option of having a connected device identified or manually selecting the device type.



If the device is created manually, you will be asked to specify the options of the annunciator. If the device has been identified, the supported options are represented by checkmarks in the HW column.

Fig. 6.8: Display of device options in the "Parameters/Device administration" menu

After the fault annunciator has been created, it appears under the name Master device or Slave device 1 to Slave device 3 in the "Parameters" main menu. The menu of a newly created slave annunciator corresponds to the menu of the master device. However, the "Reporting sequence" tab is missing, since the alarm sequences of the slave annunciators are identical to those of the master annunciator.

In this way, 1 master and a maximum of 3 slave devices can be created. The slave annunciators are displayed independently of the parameterized device name in the main menu Parameterization under the name Slave device (1 ... 3). By clicking on the recycle bin symbol, the last device in the cascade can be deleted again.

# 6.3.2.2 Submenu "Export/Import"

In this dialog, the parameterization of the fault annunciator can be exported or imported. The following functions are possible:

#### Export total parameterization

The parameters of the entire system (incl. possibly connected slave devices in cascaded systems) are compressed to a file and saved. Depending on the setting of your internet browser, this is saved as file EESsystem.pcf (protected configuration file) in the default download folder of the browser or name and location can be freely selected. The file is password protected and cannot be read. Parameters currently changed on the web interface must first be saved using the **"Accept configuration"** function before they are exported as well.

#### Import total parameterization

A system parameter file is selected via the "Browse" button and loaded and processed in the device with the "Import" button. The parameters are immediately taken over and activated. The file suffix "pcf" is necessary to recognize the file as a protected configuration file.

#### Export device parameterization

With the "export" button, the parameter file of a device (0 .. 3) selected via the option fields is stored as a password-protected zip file under the name to be selected, in the directory to be selected (default "USMDeviceX.pcf" with X as device number). The parameters that are stored on the device are exported. Changes currently made to these parameters on the web interface must first be saved in the device by "Apply configuration" before they can be exported.

The "Export HTML" button exports the selected parameter file (0 .. 3) in HTML format and displays it formatted in plain text.

#### Import device parameterization

The parameter file of a device is selected via the "Browse" button and imported into the device and processed with the "Import" button. The parameters are immediately taken over and activated. The type .pcf is necessary to recognize the file as a protected zip file.

It is also possible to import exported parameter files from older device versions (xml format instead of zip file), these must have the file type .ucf.

## 6.3.3 System

Passwords	
O Help	
Administrator	password "admin"
Old Password:	
New Password:	
Verify new PW:	
Change	
Lleor passwor	
USEI passivui	u user
New Reservord	
New Password.	
Verify new PW:	
Change	

Fig. 6.9: Submenu "Passwords" in the menu "System"

In the submenu "System" the passwords for the two users administrator and user can be changed.

Administrator (read and write rights) - admin

User with limited rights (read only) - user

A password can consist of ASCII characters and has a length limit of 40 characters.

# 6.3.4 Menu "Fault annunciator" (Master device / Slave device 1 ... 3)

55	Language H Parame	eter	¢	Config	guration	I							R	Ŧ	Î	0	
Parameter	7 System 7 Master-device	adi	min														
oorting cha	nnel Reporting sequence	Buttons	& Fur	nction	inputs	Relays Li	ED-color s	electi	ion								
Help	Print labels			ni	XML ame:	Konfigura	ation				vari	iant:	VO	00.001			
Devicen	ame: Stoermelder				c	omm-port:	6				Firmv	vare:	147	29000.000.0	005j		
Input	<b>s pyhs:</b> 32			File:	32		Rela	iys p	hys:	0				File:	0		
i i	Signal Name	оі	NC	DT		RD	J.	DF			CR1	CR2	CR3	нт			A
X16.1	Alarm/Meldung\X18.1			5	ms	0.100		5	/ 1000	ms	V			Horn is no	t locked	•	V
X16.2	Alarm/Meldung\X18.2			5	ms	0.100		5	/ 1000	ms				Horn is no	t locked	•	V
X16.3	Alarm/Meldung\X18.3			5	ms	0.100		5	/ 1000	ms	V			Horn is no	t locked	•	V
X16.4	Alarm/Meldung\X18.4			5	ms	0.100		5	/ 1000	ms	<b>V</b>			Horn is no	t locked	•	V
X16.5	Alarm/Meldung\X18.5			5	ms	0.100		5	/ 1000	ms	V			Horn is no	t locked	•	V
X16.6	Alarm/Meldung\X18.6			5	ms	0.100		5	/ 1000	ms				Horn is no	t locked	•	V
X16.7	Alarm/Meldung\X18.7			5	ms	0.100		5	/ 1000	ms	☑			Horn is no	t locked	•	V
X16.8	Alarm/Meldung\X18.8			5	ms	0.100		5	/ 1000	ms				Horn is no	t locked	-	V
X14.1	Alarm/Meldung\X16.1			5	ms	0.100		5	/ 1000	ms	☑			Horn is no	t locked	•	V
100000000	1	_	-						10			-		Lines in an			

Fig. 6.10: Menu "Master device"

The actual function of the fault annunciator is parameterized in the "System" menu. This includes the submenus:

- Reporting channels
- Reporting sequence
- Buttons and function inputs
- Relays
- Repeat relay
- LED color selection

	🖲 Language 🛛 🕅 Parami	eter	¢	Config	guration								M	±	a	0	
Parameter	/ System / Master-device	1 adr	nin														
orting cha	nnel Reporting sequences	Buttoris	8 Fur	nttion	inputs	Relays Li	D-colors	eiect	(01)								
O Help	Print labels			n	XML ame:	Konfigura	tion				vari	ant:	VO	00.001			
Devicen	ame: Stoermelder				c	omm-port:	6				Firmv	vare:	147	729000.000.0	005j		
Input	s pyhs: 32			File:	32		Rela	nys p	hys:	0				File:	0		
í.	Signal Name	01	NC	DT		RD	11	DF	a.		CR1	CR2	CR3	нт			
X16.1	Alarm/Meldung/X18.1	D		5	ms	0.100	VI.	5	/ 1000	ms				Horn is no	t locked 🔹		
X16.2	Alarm/Meldung\X18.2	13	8	5	ms	0.100		5	/1000	ms	12		8	Horn is no	t locked 👻	8	
X16.3	Alarm/Meldung\X18.3			5	ms	0.100	V	5	/ 1000	ms				Horn is no	t locked +	8	l
X16.4	Alarm/Meldung\X18.4	8	0	5	ms	0.100		5	/1000	ms	121	63	8	Horn is no	t locked 👻	5	ļ
X16.5	Alarm/Meldung\X18.5		Ő.	5	ms	0.100	(VIII)	5	1000	ms	J	D		Horn is no	t locked 🔹		interest
X16.6	Alarm/Meldung\X18.6	15	0	5	ms	0.100	V	5	/ 1000	ms	Z	10	8	Horn is no	t locked 👻	5	1
X16.7	Alarm/Meldung\X18.7			5	ms	0.100	V.	5	/ 1000	ms		0		Horn is no	t locked 🔹	6	į
X16.8	Alarm/Meldung\X18.8	15	-	5	ms	0.100	<b>X</b>	5	/1000	ms	121	8	13	Horn is no	t locked 👻	5	1
X14.1	Alarm/Meldung\X16.1	0		5	ms	0.100	2	5	1000	ms	1	D		Horn is no	t locked 👻		l
	Alarm / Faldunat V16.2	100	121	5	me	0.100	19111	5	(1000	me	191	375	100	Horn is no	t locked -		ĺ

6.3.4.1 Submenu "Reporting channels"

Fig. 6.11: Submenu "Reporting channels"

#### XML name, variant

Name and variant of the parameterization of the fault annunciator, which appears in the header lines when printing out the device parameters via the "Parameters/Device administration/Export/Import" menu. The content can be defined by the user.

#### **Device name**

Here you have the option of assigning a designation consisting of 40 ASCII characters for the fault annunciator. This is used to identify the device and is transferred to the BSM during parameterization, stored there and inserted for identification when the labeling strip is printed.

#### **COM-Port:**

This field displays the parameterization port of the PC set in the "Serial interface" main menu.

#### Labeling strips

Clicking on the "Labeling strips" button opens a window with the labeling strips. Strips with 8 channels each and a strip for the key labeling are displayed. The alarm texts are executed according to the labels of the channels. The labeling of the keys is done according to the information on the "Buttons and function inputs" dialog page. If a label is too long, the corresponding line is displayed in red and should be corrected, otherwise only the visible text is printed. Clicking on a text in the labeling strip opens a dialog for editing the text. The paper format DIN A4 landscape must be selected at the printer.

Print Alarm/Mele Alarm/Meldu X14.1 X12.1 X10.1 Alarm/M X14.2 Alarm/ X10.2 Alarm/N X12.2 Ackn Horn Alarm X14.3 Alarm X12.3 Alarm X10.3 Ackn Alarm/ X12.4 Alarm X14.4 X10.4 Alarm/I Alarm/N X12.5 Alarm/N X14.5 X10.5 Alarm/ X14.6 X12.6 X10.6 Alarm X14.7 Alarm X12.7 Functi Alarm X10.7 Alarm/ X14.8 Idung Alarm X12.8 Alarm/ X10.8 Input 1...8 Input 9...16 Input 17..24 Annunicator example Device 0

Fig 6.12: Print version of a labeling strip

The following parameters can be set in the table for each individual signal channel.

Field	Explanation
1	Input = Channelnumber (fixed assigned)
Signal name	Designation of the respective channel
	This designation will be used when printing the labelling strips. A 2-line labelling can
	be realised by separating the second line by "\" (backslash) from the first line (e.g.
	Irf.\Circuit breaker switch).
01	Operation indication
	If this box is upshacked (default setting), the signal will be preserved association.
	in this box is unchecked (default setting), the signal will be processed according to the chosen reporting sequence (see page Reporting sequence)
	By defining the signal to be operation indication or fault annunciation, the LED-colour
	will automatically be set according to the settings on the page "I ED-colour"
	Default settings: operation indication = green, fault annunciation = red.
NC	Normally closed principle of the inputs (when checkbox is ticked)
_	Normally open principle: application of a voltage at the input triggers an alarm.
	Normally closed principle: voltage drop at the input triggers an alarm.
	Default setting: Checkbox not ticked – normally open principle.
DT	Debouncing time
	The debouncing time defines the timespan for which a signal must continuously be
	applied before an alarm is issued. This prevents multiple alarms in the case of a
	bouncing switch.
	Personal delay
	The alarm delay delays a permanently pending alarm (debounced and monitored for
	flutter) before it is processed. This is intended to suppress error alarms that would
	occur, for example, if a value is only briefly exceeded or underrun. The time span is
	significantly greater than the response delay (debouncing time). The time span goes
	from 032400 s (9 h) and is definable in two grids (value < 30 s in a
	1 ms grid and for values > 30 s in a 1 s grid).
	The value can be entered in three formats:
	1. pure numerical value e.g. 100 interpretation in seconds $\rightarrow$ 100 s
	2xxx e.g100 interpretation in ms $\rightarrow$ 100 ms
	3. mmm:ss.xxx Interpretation in minutes, seconds and milliseconds
	e.g. 111.22.0 $\rightarrow$ 111 minutes and 22 seconds The checkboxes $ $ and $ $ for rising and falling edge define for which signal edge
	the alarm delay is active
	Checked: delay is active for coming alarm
	checked: delay is active for receding alarm
DF	The <b>flutter suppression</b> is to prevent that (e.g. due to a loose contact) an input is
	always switched on and off and thus the alarm changes constantly. The flutter
	suppression acts after the response delay (debounce time).
	If an input changes more often than the defined number of edges within the defined
	flutter time, the flutter suppression takes effect and marks the signal channel as faulty.
	Fluttering time: 0 ms 65535 ms, ~1 min., grid 1 ms
	Number of edges: 0 255
	Assignment to collective reports
CB3	If one of these check boxes is activated, the alarm triggers the corresponding
	collective alarm. Multiple assignments are possible. All alarms assigned to a collective
	alarm form a group. This assignment is also important for alarm acknowledgement
	and RESET.

Table 6.1a: Parameters of reporting channel

Field	Explanation				
HT	Horn triggering				
	None:	Alarm does not trigger horn			
	With horn lock:	Horn acknowledgement only possible after lamp acknowledge			
	No horn lock:	Horn acknowledgement always possible			
А	Activation of the alar	m channel			
	If this checkbox is untion	cked, the channel will not be processed. The alarm will be			
	ignored within the complete system.				
	Default setting:	channel activated			

Table 6.1b: Parameters of the reporting channels

#### Explanation of the delay times

The following drawing illustrates the mode of operation of the two delay times and the defluttering. The options for triggering of the optionally integrated repeat relays is displayed as well (see section <u>Repeat relays</u>).



Fig. 6.13 Schematic illustration of the alarm processing in the BSM

#### Debounce time

Closing a contact may cause several edge changes before the contact is permanently closed. Due to the short response time when detecting alarms, several alarms could therefore be generated during the closing of the contact. To prevent this, the debouncing time can be set in 1 ms steps up to a time of 1000 ms. The signal is not recognized as valid until it is permanently present beyond this time period. However, the time stamp is still set with the first edge of the signal and not only at the time of the validity of the signal.

#### Response delay (alarm delay)

The response delay delays a permanently pending alarm (debounced and monitored for flutter) before it is displayed, forwarded or deleted. This is to suppress error alarms that would occur, for example, if a value is only briefly exceeded or underrun.

#### Example:

The monitoring contact of a thermostat triggers briefly before the corresponding temperature is reached by the conditional control loop time. Because this short overtemperature should not be reported as an malfunction, the alarm can be suppressed with the alarm delay. Only alarms that are present for longer than the alarm delay are processed in the alarm sequence or output at the output-parallel repeat relays.



Fig. 6.14: Time diagram with a response delay of 50 ms and a alarm delay of 150 ms





For device and channel designation, all characters from A...Z and 0...9 are allowed. The special characters ", { } | \$ & # ; " are not allowed. For channel designations, "," (backslash) is used as separation mark to start a new line.

Reporting channel Reporting sequence	Buttons & Function inputs Relays LED-color selection					
O Help						
Reporting gro	up:					
Signalling	1-Frequency	•				
Reporting sequence	new value	•				
Collective report	e report output parallel static					
Horn-control	retriggerable					
Horn						
Internal horn active	5					
Horn priority ackn.	8					
Horn ackn.	manual	C automatic O Seconds				

6.3.4.2 Submenu "Reporting sequence" (only master device)

Fig. 6.15: Submenu "Reporting sequence"

In this submenu, the reporting sequence and the horn control are parameterized. In cascaded systems, the same reporting sequence applies to all devices, which is why this submenu is only available on the master device. In order to be able to adapt the sequences as flexibly as possible to the respective requirements, these are composed of individual components.

### **Reporting sequence**

Designation	Selection options	Note					
	1-Frequency	1- Frequency flashing light					
	2-Frequency	2- Frequency flashing light					
Signaling		Self-clearing alarm: Alarm is immediately displayed					
	State display	as an acknowledged alarm and goes when the					
		associated input is no longer present.					
Reporting	New value	New value alarm					
sequence	First-up value	First-up value alarm					
3000000	Steady light	Only selectable in conjunction with 2-frequency					
		The collective alarm is set with the first coming					
	Input parallel static	alarm and goes, regardless of the					
		acknowledgement, with the last going alarm.					
		The collective alarm is set with the first incoming					
		alarm. With each further alarm, the collective alarm					
	Input parallel static dynamic	is deleted for approx. 0.8 s and then set again.					
		When all alarms have gone, the collective alarm is					
		permanently deleted.					
		The collective alarm is set with the first incoming					
	Output parallel static	alarm. The collective alarm is only deleted when all					
		The collective clerm is act with the first coming					
Colloctivo alarm		alarm With each further alarm the collective alarm					
	Output parallel static	is deleted for approx 0.8 s, then set again When					
	dynamic	all alarms have done <b>and</b> have been					
	aynamic	acknowledged the collective alarm is permanently					
		deleted.					
		The collective alarm is activated for approx. 0.8 s					
	Dynamic	with each incoming alarm.					
	land the shall at static all t	The collective alarm is set with the first coming					
	Input parallel statically	alarm and goes with the last going alarm or when					
	acknowledgeable	all alarms have been acknowledged.					
		The collective alarm is set with an upcoming alarm.					
		When the alarm is acknowledged, the collective					
	acknowledgeable	alarm is deleted, even if alarms are still pending.					
	Horn can be triggered again	The horn is activated again with the next alarm,					
Horn control	tion can be inggered again	even if alarms are already pending.					
	Horn cannot be retriggered	The horn is only activated again for subsequent					
	again	alarms if no alarms are pending.					

Table 6.2: Parameters of the reporting sequence



More detailed information on the reporting procedures and their designation can be found in the separate document "Description of the reporting procedures" with the document designation "SM-MA-ZI-UK".

Horn
------

Designation	Selection options	Note				
Internel here estive	Activated	The internal and external horns are controlled in parallel.				
Internal norn active	Deactivated	The internal horn is switched off, the horn contact for connecting the external horn is still active.				
Horn priority	Inactive	The alarm can be acknowledged according to the Horn activation setting of the "Reporting channels" submenu.				
acknowledgement	Active	The alarm can only be acknowledged when the horn has already been acknowledged.				
Horn	Manual	Horn is acknowledged manually by pushbutton or via a function input.				
acknowledgement	Automatic	Horn is automatically acknowledged after the set time.				
Horn mute	No triggering when button is pressed	The horn is not triggered or automatically acknowledged after a parameterizable time if a key parameterized for this purpose or a parameterized function input is pressed or activated. (see section <u>Buttons and function inputs</u> )				
	Automatic acknowledgement	Horn is automatically acknowledged after the set time. This time can be selected differently from the time for automatic horn acknowledgement in normal operating mode.				

#### Table 6.3: Parameter of the horn function

Please note the connection between the "Horn priority acknowledgement" parameter and the "Horn activation" parameter of the "Reporting channels" submenu, which can be set individually for each channel. The "Horn priority acknowledgement" parameter applies to all signal channels and has the higher priority. If it is set to "active", the alarm can only be acknowledged after the horn has been acknowledged.

# 6.3.4.3 Buttons and function inputs

	-	-	10		-	
	Button 1	Button 2	Button 3	Button 4	Function input 1	Function input
Label	Quitt. Hupe	Quittierung	Lampentest			
Acknowledege 1						
Acknowledege 2	8				10	
Acknowledege 3						
Reset 1	8		8	13		8
Reset 2						
Reset 3	8	8	8	8	11	2
Horn						
Lamp test		8	192	13	23	13
Function test		10	1	1917	PE	1992

On this dialog page, the functions of the fault annunciator listed below are assigned to the buttons T1 ... T4 and the function inputs 1 and 2. Multiple assignments are possible.

The texts entered in the "Labeling" line are printed out together with the labels of the reporting channels by pressing the "Labeling strips" button in the "Reporting channels" submenu.

Lia.	6 16.	Cubmonu	Duttono	and	function	innuto"
гıу.	0.10.	Submenu	"DULLOHS	anu	IUNCION	inpuis

Function	Meaning
Acknowledgement 1, 2, 3,	Acknowledgement optical for alarms of groups 1, 2, 3 or unassigned
unassigned	alarms
Reset 1, 2, 3, unassigned	Reset for alarms of the collective alarm groups 1, 2 or 3 or unassigned
	alarms
Horn	Acknowledgement acoustic (horn)
Lamp test	Lamp test
Test function	Simulation of the excitation of all inputs
Mute function	As long as this operating mode is activated, the horn is not triggered or
	automatically acknowledged after the parameterized time.
Unmanned function	As long as this operating mode is active, there is no visual or audible
	output of pending alarms. The internal alarm processing and, if
	necessary, the control of relays or the output of alarms via interface
	remain active. Alarm acknowledgement at the fault annunciator is
	deactivated.

Table 6.4: Parameters of the assignment of buttons and function inputs



A group is formed by all alarms that are included in the same collective alarm. Unassigned alarms are alarms that are not assigned to a collective alarm.

# 6.3.4.4 Submenu "Relays" (function relays)

In this submenu, the assignment of the 4 function relays to the individual fault alarm functions, buttons or function inputs takes place. Several events can be defined for a relay, e.g. the grouping of collective reports. As soon as one of these events occurs, the relay switches. When the last triggering event has gone, the relay drops out again. For each relay, a check mark in the "Inverted" field can be used to specify whether the switching function or its negation is executed. For example, the relay then drops out when the collective report occurs.

	1.1			
	Relay 1	Relay 2	Relay 3	Relay 4
Inverted	۵	8	8	
Collective report 1	V			
Collective report 2	8		5	
Collective report 3				-
Horn	E		12	
Alive				
Function input 1	Ð	D	5	
Function input 2				
Interface	0			
Button 1				
Button 2	Ð	10	8	
Button 3				
Button 4	5	8	8	
Button mode	static 🔹	static 💌	static 👻	static -
Wipe delay	100 ms	100 ms	100 ms	100 ms

Fig. 6.17: Submenu "Relays"



The assignment is made via matrix whose rows represent the triggering events (e.g. keystroke) and whose columns represent the relays. Realized links are marked by check marks.

Function	Meaning
Inverted	If the box is checked, the negation of the switching function is executed.
Collective alarm 1, 2, 3	The relay is activated by collective alarm 1,2 or 3.
Horn	Horn control
Alive	Live contact of the self-monitoring (permanently assigned to relay 4)
Function input 1, 2	Function input controls relay output
Interface	Control via interface (e.g. IEC 60870-5-101/104 or IEC 61850). Pulse
	output with set wipe duration is possible.
Button 1 4	Button controls relay output
Button mode	Relay function when controlled via a button or the interface
	Static – The relay is energized as long as the button remains pressed.
	Toggle – The bistable relay changes its state with each excitation (flip-flop
	function)
	Wipe – Relay switches with each excitation and drops out again after
	the wipe duration (10 ms 10 000 ms).

Table 6.5: Function assignment of the relays

# 6.3.4.5 Repeat Relays

porting char	nnel Reporting sequ	ience Buttons & Function input	s Relays Repeat relay	LED-color selection WAP-v	vindows	
🛛 Help						
Relay	Inputs	Relay is active	Inverted	Output parallel	ı/o	Pulse Length
1	1 •	V				500 ms
2	2 🗸					500 ms
3	3 🗸					500 ms
4	4 •					500 ms
5	5 👻					500 ms
6	6 👻					500 ms
7	7 🔹					500 ms
8	8 👻					500 ms
9	9 🗸					500 ms
10	10 🔹					500 ms
11	11 -	V				500 ms
12	12 •					500 ms
13	13 👻					500 ms
14	14 🗸					500 ms

#### Fig. 6.18: Submenu "Repeat Relay"

The optionally available relay cards (with 8 NO contacts each) are independent of the 4 function relays described in the previous section. During parameterization, only the relay groups available in each case are displayed. For each relay (channel) it can be defined whether it is controlled via a device input, a device function or the interface. The following specifications can be made.

#### Inputs

Here you can define how the relay is controlled. The following options are available:

- Function collective alarm 1, 2 or 3
- Function horn control
- Available galvanic alarm inputs

#### Relay is activated

By removing the check mark, the control of the relay by the above functions and inputs can be deactivated.

#### Inverted

If this check mark is set, the negation of the respective function is executed. For example, the relay then drops out when the collective alarm occurs and picks up when no collective alarm is present.

#### Output parallel

If the relay is activated by an alarm input, it can be defined whether it follows this input directly (tick not set) or remains activated until the alarm has been acknowledged (tick set) - signaling of the stored alarm.

Reporting channel	Reporting sequence Buttons & Fur	nction inputs Relays LED-color selection	n en
<b>O</b> Help			
Ú.	Signal Name	operating indication	fault annunciation
		off on	off on blink
X16.1	Alarm/Meldung X18.1		
X16.2	Alarm/Meldung X18.2		
X16.3	Alarm/Meldung X18.3		
X16.4	Alarm/Meldung X18.4		
X16.5	Alarm/Meldung X18.5		
X16.6	Alarm/Meldung X18.6		
X16.7	Alarm/Meldung X18.7		

6.3.4.6 Submenu "LED color settings"

Fig. 6.19: Submenu "LED color settings"

On this dialog page, the LED colors for operating and fault alarms can be set for each channel. The BSM is delivered with RGB-LED.

RGB-LED - LED off (grey box) ) or the colors red, green, yellow, blue, orange, white

The selection "LED off" is only available for the "Off" state.

#### Operating alarm

For operating alarms, the colors can be set for two states.

#### Fault alarm

For the fault alarm, one of the above colors is set for each of the states "Off", "On" and "Flashing".



Please note that different color settings are always required for the "Off" or "On" state of an LED.

# 6.3.5 Menu "Modbus"

оныр Serial interfac	.e			
Baudrate 1:	19200 even			~
Transceiver 1:	() R5232		• RS485	
Modbus				
Slave Id:	inactive: O	Modbus RTU: 💿		

Fig. 6.20: Menu "Modbus"

This menu is used to set the serial interface (terminal X6) on the optional interface card. This interface is used for Modbus communication.

The following parameters can be set:

Baud rate	- 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud
Parity	- none, even, odd

The interface can be switched between RS232 and RS485.

If the Modbus is activated by selecting the "Modbus RTU" radio button, an additional input field opens for defining the Modbus slave address of the fault annunciator.



For further information about the Modbus interface please refer to the separate documentation MSM-SMODB-BA-UK.

# 6.4 Main menu "Configuration"



Fig. 6.21: Open main menu "Configuration"

#### Apply configuration

Saving the changed parameters of the currently edited device in the RAM of the PC.

#### Apply all 4 configurations

With this button, the parameters of all devices (basic device and the possibly connected extensions (slave device 1 ... 3) are stored in the RAM of the PC.

#### **Dismiss configuration**

Discard all changes made in the session (since the last "Apply configuration").

Please note that the parameterization needs to be saved either

- with the menu command "Write parameters to device" in the device
- or with "Parameter/System/Device administration/Export/Import" in a file on the computer.

Otherwise, the current changes will be discarded once you log out.

#### **Factory defaults**

Resetting all parameters to the factory setting

#### Identify device

Identifying and creating the device (for fault alarm cascades of all connected devices)

#### Read parameters from device

Read out the parameters stored in the device. After the readout, the data in the PC must be updated using the "Accept configuration" or "Accept all 4 configurations" action.

#### Write parameter to device

With this function, the configuration created on the PC is written to the device. The fault annunciator is then restarted automatically.

# 6.5 Main menu "Monitor"

The monitor is a diagnostic tool for the fault annunciator and any slave devices connected in the cascade. In this display, the LEDs of the fault annunciator are shown with their states (flashing, on and off).

Fables									1		Current device errors
PECIEI.											Current device entris
1					ntheitung ntheitung ntheitung ntheitung ntheitung ntheitung ntheitung	C==				•	 Image of alarms at issue
	Q Anto		( it is a set	ų <del>a</del>	or state						Status of:
Ca	Rep. 1	Ocil. Rep. 2	Col. R	) ep. 5	O Function1	C	)	) no lest	Horn	←	 Collective reports Function inputs Lamptest, Horn
Col	Rep. 1 Ackin. Group2	Col. Rep. 3 n. p3 Group	t Col. R t Group2	) ep. 3 Reset Group3	Function1	Functo Ackr. Horn	) M2 Famil Rates 1	no lest unol. Hay 2 Rat	Norn Reg 1 Reg 1	←   ←	 Collective reports Function inputs Lamptest, Horn Functions and function relays
Car Lup1 rpeat	Rep. 1 Ackn. Group2 Relays: Relay 2	Col. Rep. 1 Col. Rep. 1 Rese Group	t Col. R t Reset fr Group2 ( Reizy 4	) Reset Froup3 Rolay 6	Function st Lamp test Raizy 4	Function Action Horm	Fund Reint 1	no lest unot. May 2 Ref	Norn Norn RE Reit	←   ←	 Collective reports Function inputs Lamptest, Horn Functions and function relays
cor up1 tipe at sizy 1 sizy 9	Rep. 1 Ackn. Group2 Relays: Reiay 2 Reiay 10	Col. Rep. 1 Col. Rep. 1 Rese Group Relay 3	t Col. R t Reset f Relay 4 Relay 12	) Reset Group3 Relay 6 Relay 11	Function1 cctor Lamp st Reizy 8 Reizy 14	Functor Functor Horn Relay 7 Relay 16	Fund. Razz 1 Reizy 1 Reizy 18	no lest unot. Py nay 2 Tax	Norn Rein Rein Rein Rein Rein Rein Rein Rei	← ← ←	 Collective reports Function inputs Lamptest, Horn Functions and function relays Repeat relays

Fig. 6.22: Monitor - a diagnostic tool

For each device (master or slave 1...3) created in "Parameters / Device administration", a separate monitor screen can be called up via the associated tabs.

The 13 yellow buttons symbolize functions and can be "actuated" by mouse click, if logged in as an admin, thus triggering the corresponding action (acknowledgement, function test ...).

The states of the 4 function relays and, if available, the 1:1 relays are also displayed (red - excited, white - idle state).

# 7 Usage and product life cycle

# 7.1 Maintenance

To ensure a high life expectancy of the product, regular maintenance activities are required, which are limited exclusively to cleaning and care activities for the devices used. These may also only be carried out by trained specialist personnel. Improperly performed maintenance work can lead to partial or complete failure of the product.



# 7.2 Repair

In the event of partial or complete failure of the product, repair work may be necessary which, due to the complexity of the device, may only be carried out by the manufacturer. Improperly performed repair work will void any warranty or guarantee claims. Please contact our customer service.



Technical service: Elektra Elektronik GmbH & Co Störcontroller KG Hummelbühl 7-7/1 71522 Backnang + 49 (0) 7191/182-0 Tel.: Fax: +49 (0) 7191/182-200 E-Mail: info@ees-online.de

# 7.3 Decommissioning

In the event of temporary or permanent decommissioning of the product, proceed according to the instructions below. These may only be carried out by trained specialist personnel. Improperly performed activities can lead to partial or complete failure of the product.



Warning!

All decommissioning work must only be carried out when the device is deenergized!

#### Decomissioning:

- Switch off the power supply to the device •
- **Disconnect wiring** •
- Release the retaining clips and remove the unit from the front panel or door by pulling it • forwards.

Proper storage until recommissioning or shipment to the manufacturer's customer service department requires suitable premises in accordance with the storage conditions in the Technical data section. In case of complete decommissioning, proceed as described in section 7.6 Disposal.

In case of recommissioning, proceed as described in section 4 Mounting and installation.

# 7.4 Packaging and transport

If it is necessary to transport the product for repair purposes or relocation, appropriate packaging and transport conditions must be ensured so that the device is not impaired in any way during transport.



#### Packing instructions:

Please ensure suitable shipping packaging (original packaging if possible). Please observe country-specific regulations for shipping electronic products.

# 7.5 Spare parts

The partial or complete failure of the product can, if necessary, be prevented by appropriate repair activities using suitable spare parts, which, due to the complexity of the device, may only be carried out by the manufacturer. Please contact our customer service.



#### Technical service:

Elektra Elektronik GmbH & Co Störcontroller KG Hummelbühl 7-7/1 71522 Backnang + 49 (0) 7191/182-0 Tel.: +49 (0) 7191/182-200 Fax: E-Mail: info@ees-online.de

# 7.6 Disposal

The disposal of defective products or old devices can potentially have negative effects on health and the environment, therefore they must be disposed of in a harmless and environmentally friendly manner in accordance with the regional legal disposal regulations. Alternatively, a return shipment to the manufacturer should be considered.

#### **Disposal instructions:**

Returning the packaging to the material cycle reduces the volume of waste and saves raw materials. Dispose of packaging materials that are no longer required at the regional collection points for the dual recycling system. If possible, save the packaging during the warranty period so that the device can be properly packaged in the event of a warranty claim.



The disposal of the device itself falls under the scope of electronic waste. If necessary, contact your local waste disposal company for information on suitable disposal methods. Do not dispose of electrical devices in household waste, but use the regional collection points. If electrical devices are disposed of in an uncontrolled manner, hazardous substances may enter the groundwater during weathering and thus enter the food chain or poison the flora and fauna for years.



Contact