

Indicator installation manual

1. All moveable parts are stripped before mounting, this includes:

- fixing nut
- o-ring pad (o-ring pad is part included only for certain indicator models)
- o-ring (rubber seal)

2. Mount the indicator into the panel.

3. From under the panel equip the indicator with the o-ring followed by o-ring pad and fix the indicator with fixing nut.

